

CN1	P1(J1)	WIRE COLOR	
1	2	Gray	
2	1	Stripe	
3	4	Gray	
4	3	Gray	
5	6	Gray	
6	5	Gray	
7	8	Gray	
8	7	Gray	
9	10	Gray	
10	9	Gray	
11	12	Gray	
12	11	Gray	



ASSEMBLY INSTRUCTIONS:

- 1) NOTCH DOWN QD5747
- 2) CUT DOWN UNUSED WIRES AT J1 CONNECTOR ON FLYING LEAD





CONVERTS FROM 0.50MM PITCH FFC/FPC INTERFACE TO RIBBON WIRE SEE NEXT PAGE FOR PICTURES AND ADDITIONAL INFORMATION

12/1/21

PT

DWG BY:	PT	DATE: 9/18/15	DRAWINGS ARE NOT TO SCALE. ALL DIMENSIONS ARE INCHES UNLESS OTHERWISE SPECIFIED. ALL TOLERANCES ARE +/- 0.50" UNLESS OTHERWISE SPECIFIED		
CHK BY:		DATE:			
APPR: -		DATE: -			
		REVISION HIST	TORY		
REV				DATE	APPROVED
	INITIAL RELEASE		6/27/06	GLR	
DRAWING UPDATE, LENGTH INCREASE		9/18/15	PT		

Assembly Instructions Update

Quadra	ngle	Pro	ducts	Ιn

Quadrangle Products Inc. 28 Harrison Ave Suite 105, Englishtown, NJ 07726 Fax: 732-792-8305

J 07726 Fax: 732-792-8305

© Copyright 2006 Quadrangle Products Inc.
This document is confidential and proprietary to Quadrangle Products
Inc. and shall not be reproduced, copied, used, or issued as the basis of
manufacturing and/or sale of equipment, material, or any other item.
Quadrangle Products Inc. has the sole and exclusive ownership rights
to this document and information contained herein.


RT-700G-12-RIB CABLE KIT


FPC Adapter Part Number:

QD5747AD (33 Conductor Base) (2-33 Conductors When Customized)

FPC Adapter Part Number:

QD5745AD (50 Conductor Base) (2-50 Conductors When Customized)





Ribbon Wire Flying Lead Part Number (40C): QD6020 (Used with QD5747AD)
Ribbon Wire Flying Lead Part Number (50C): QD6022 (Used with QD5745AD)